

CLEAR SERUM FOR OILY SKIN WITHOUT OIL PHASE 6939

Formula

Α	•	Water	20.0%
	•	LIPACIDE C8G (Capryloyl glycine – SEPPIC)	1.0%
	•	MONTANOX 20 (Polysorbate 20 – SEPPIC)	2.0%
	•	Sodium hydroxyde	Qs
В	•	SEPINOV EMT10 (Hydroxyethylacrylate / Sodium acryloyldimethyl taurate copolymer – SEPPIC)	2.0%
С	•	Ethanol	5.0%
	•	SEPICIDE HB (Phenoxyethanol/Methylparaben/Ethylparaben /Propylparaben /Butylparaben - SEPPIC)	0.3%
	•	Water	Qsp 100%

Procedure

Solubilize Lipacide C8G and Montanox 20 under mecanic stirring, in water heated at 80° C (the mixture should be clear).

Cool at around 30° C then adjust the pH around 5.2 with the sodium hydroxide. Introduce step by step Sepinov EMT 10 in phase A under mixing. Add water then Ethanol and Sepicide HB.

Comments

INTEREST : Gel with a LIPACIDE C8G	a clear apparence and a softness texture A glycine biovector and skin acidifying agent, it protects the skin and helps maintain its ecosystem. It also protects cosmetic products by increasing the microbiological stability of formulas with a low preservative content.
MONTANOX 20	Solubilizer
SEPINOV EMT 10	Powder polymer « 2 in 1 » thickener in a wide pH range (3-10) ,ready to use , with a Excellent emulsifying and stabilizing power at low level -Innovative chemical structure with a good compatibility with specific actives ingredients and supple texture easy to pick up
SEPICIDE HB	Preservative

Characteristics

SEPPIC SA 33(0) 1 40 62 55 55

SEPPIC Inc 1 973 882 5597 **SEPPIC UK Ltd** 44 208 577 8800

SEPPIC Italia Srl 39 02 38009110

Givaudan Lavirotte SA 33(0) 4 78 61 55 00 SEPPIC China 86(21) 64 66 01 49 SEPPIC GmbH 49(0) 220 3890 3100

SEPPIC Belgium NV 32 3 250 3911



Aspect	Clear gel
рН	Around 5.2
Viscosity	Around 1 500 mPa.s
Stability	Stable at RT – 45°C

6939 – SEPPIC

Since this formula has not been the object of a toxicological study, the use and handling of the products proposed is purely indicative and SEPPIC accepts no responsibility for their use by another party.

SEPPIC SA 33(0) 1 40 62 55 55

Givaudan Lavirotte SA 33(0) 4 78 61 55 00 **SEPPIC Inc** 1 973 882 5597

SEPPIC China 86(21) 64 66 01 49 **SEPPIC UK Ltd** 44 208 577 8800

SEPPIC GmbH 49(0) 220 3890 3100 SEPPIC Italia Srl 39 02 38009110

SEPPIC Belgium NV 32 3 250 3911