



TWO-PHASE SHOWER GEL « GREEN APPLE » 6958

Formula

A	<ul style="list-style-type: none">• Sodium laureth sulfate• PROTEOL APL (<i>Sodium cocoyl apple amino acids - SEPPIC</i>)• AMONYL 380BA (<i>Cocamidopropyl betain - SEPPIC</i>)• Glycerin• Parfum / Fragrance• MONTANOX 20DF (<i>Polysorbate 20 - SEPPIC</i>)• SEPICIDE HB (<i>Phenoxyethanol/Methylparaben/Ethylparaben /Propylparaben /Butylparaben - SEPPIC</i>)• SEPICIDE CI (<i>Imidazolidinyl urea - SEPPIC</i>)• Colorant / Dye• Aqua / Water	14.0 % 5.0 % 5.0 % 0.8 % 2.0 % 0.5 % 0.3 % 0.2 % 0.01 % Qsp 100%
B	<ul style="list-style-type: none">• Polyisobutene	22.0 %
C	<ul style="list-style-type: none">• Lactic acid	0.1 %

Procedure

Solubilize Sodium laureth sulfate in the water then add the ingredient of phase A, mix well after adding each of them. Introduce phase B into phase A under moderate stirring. Adjust the pH with C component.

Comments

PROTEOL APL	Fruit surfactant , derived from apple juice essential amino-acids, for a gentle approach : gentle approach for the touch, for the skin & the eyes and also for the environnement.
AMONYL 380BA	Amphoteric co-surfactant.
MONTANOX 20DF	Solubilizing surfactant.
SEPICIDE HB	Preservative.
SEPICIDE CI	Preservative.

SEPPIC SA
33(0) 1 40 62 55 55

Givaudan Lavitrotte SA
33(0) 4 78 61 55 00

SEPPIC Inc
1 973 882 5597

SEPPIC China
86(21) 64 66 01 49

SEPPIC UK Ltd
44 208 577 8800

SEPPIC GmbH
49(0) 220 3890 3100

SEPPIC Italia Srl
39 02 38009110

SEPPIC Belgium NV
32 3 250 3911



Characteristics

Aspect	Bi-phasic solution : green phase on the bottom - white phase on the top
pH	around 6
Viscosité	< 50 mPa.s
Stability	Stable at RT - 40°C - 4°C

Notes

Dye : Vert Ref W7000 (WACKHERR)

Fragrance : Pomme Granny Ref X024720 (QUEST)

6958 – SEPPIC – 0405

Since this formula has not been the object of a toxicological study, the use and handling of the products proposed is purely indicative and SEPPIC accepts no responsibility for their use by another party.

SEPPIC SA
33(0) 1 40 62 55 55

Givaudan Lavirotte SA
33(0) 4 78 61 55 00

SEPPIC Inc
1 973 882 5597

SEPPIC China
86(21) 64 66 01 49

SEPPIC UK Ltd
44 208 577 8800

SEPPIC GmbH
49(0) 220 3890 3100

SEPPIC Italia Srl
39 02 38009110

SEPPIC Belgium NV
32 3 250 3911