



MAKE UP

# AS40107 | TWIST YOUR FACE

## Color correcting GELTRAP™



**Shine with your performances and not with your skin, thanks to this mattifying & anti-redness corrector!**

*Fresh, light & efficient, this corrector has all the skills to become your new dance accessory!*



Geltrap

<b>A</b>	Aqua / Water	Up to 100 %
	<b>SEPIPLUST™ S</b>	<b>1.60 %</b>
	<b>AQUAXYL™</b>	<b>1.50 %</b>
	<b>EQUIBIOMET™</b>	<b>1.00 %</b>
	Glycerin	3.00 %
<hr/>		
<b>B</b>	<b>EASYNOV™</b>	<b>2.00 %</b>
	<b>SEPIMAT™ H10</b>	<b>1.00 %</b>
	<b>EMOSMART™ L15</b>	<b>2.00 %</b>
	<b>EMOSMART™ L19</b>	<b>3.00 %</b>
	Phenoxyethanol - Ethylhexylglycerin	0.80 %
	Fragrance / Parfum	0.10 %
	Titanium Dioxide - Stearoyl Glutamic Acid	2.00 %
	C.I. 77288	0.40 %

With WESOURCE


### Green GELTRAP™ / Packaging: Pump

**VISCOSITIES:** 1M at RT: 32,000 mPa.s Brookfield LV4-6 /  
**Recovery at RT (after 1M at 45°C):** 31,000 mPa.s Brookfield LV4-6.

**STABILITY:** 1M at RT, 45°C & in thermal cycles from -5 to 40°C. Stable after centrifugation (30,000 rpm, 20 minutes).

### FORMULATION ADVICES: Pilot - 7 kg - VMC4 Versamix

Add water and SEPIPLUST™ S into the main tank and homogenize (3,000 rpm, 4 minutes). Add the rest of phase A into the tank and stir (50 rpm, 15 minutes). In a separated beaker, mix phase B by IKA (Ultra-Turrax T25) rotor-stator 9,500 rpm for 4 min. Add phase B into phase A and start agitation to homogenize (50 rpm, 20 minutes).



**SEPIPLUST™ S** efficiently stabilizes & disperses the formula green pigments. These are rubbing out the redness caused by workout.

*(Hydroxyethyl Acrylate/Sodium Acryloyldimethyl Taurate Copolymer - Polyisobutene - PEG-7 Trimethylolpropane Coconut Ether)*

**Pre-neutralized & easy-to-use polymer.** Very good resistance to electrolytes in a wide range of pH (3-12) thanks to associative behaviour. Good compatibility with pigments.

The **GELTRAP™** technology, created by **EASYNOV™ SEPIPLUST™ S**, brings freshness & easy spreading, ideal for the show. *(Octyldodecanol - Octyldodecyl Xyloside - PEG-30 Dipolyhydroxystearate)*

Liquid lipophilic emulsifier; It realizes emulsions with an **internal gelled aqueous phase extra-rich in water** by a **cold process** with gentle stirring; the **GELTRAP™** emulsions. Novel formulation form, offering surprising textures: **freshness & cushion effect.**

**EMOSMART™** both grades association provides a light application with a soft & dry finish.

**Non polar & biodegradable, bio-sourced** emollients. **High purity** alkanes.

**EMOGREEN™ L15** (C15-19 Alkane) / **EMOGREEN™ L19** (C15-19 Alkane)  
*(\*Plant-based & Renewable)*

**SEPIMAT™ H10** mattifies & absorbs the shine due to workouts.

*(Methyl Methacrylate Crosspolymer)*

**EQUIBIOMET™** balances the cutaneous microbiota for a harmonized complexion. *(Propylene Glycol and Arctium Lappa Root Extract)*

Extracted from the roots of the famous Great Burdock (*Arctium lappa*), this active ingredient **maintains the delicate skin-microbiota equilibrium**, for a **perfect & harmonious skin**. Tested *in vivo* & *in vitro*, it has shown **powerful soothing properties & reinforces skin barrier.**

**AQUAXYL™** reinforces the moisturizing power of the glycerin to create a powerful skin protective synergy! *(Xylitylglycoside - Anhydroxylylitol - Xylitol)*

**Moisturizes & restructures the skin by harmonizing its hydric flow** (*in vitro* & *in vivo* proven).

**ADDITIONAL INGREDIENTS:** Phenoxyethanol - Ethylhexylglycerin: EUXYL PE9010 (SCHÜLKE & MAYR) / Fragrance: 86395991 (DROM) / C.I. 77288: Chromium Oxide Green, UNIPURE GREEN LC 788 (SENSIENT) / Titanium Dioxide - Stearoyl Glutamic Acid: BTD - ASG2 (KOB0).

**A formula related to ATHLEISURE BEAUTY concept**

More informations available on [seppic.com](http://seppic.com)

A perfectly mattified  
complexion!

Anti-redness (green pigments)

Freshness, lightness  
& efficiency

**SEPPIC**

All information contained herein is intended merely to demonstrate the utility of Seppic products, and should not be construed as granting license to practice any compositions or methods covered by a patent or a patent application. All information contained in this specific technical documentation is believed to be accurate and has been set up by Seppic according to its own described methods and processes. Seppic however does not assume any liability or risks involved in the use of its products for the preparation and the assessment of the hereinabove formulation since the condition of use are beyond its control. Seppic customer must insure that the duplication of the hereinabove formulation is not infringing any intellectual property rights and that it complies with any regulatory status.

**Air Liquide**  
HEALTH CARE

A company