



SKIN CARE

# EU07434 | BLACK POP ART

#Purifying#Multimasking

O/W  
Emulsion

#PurifyYourTZone!

Skin equilibrium

<b>A</b>	Aqua/Water	Up to 100%
<b>A'</b>	Aqua/ Water Glycerin <b>PROTEOL™ APL EF</b> Charcoal powder	30.00% 2.00% <b>1.00%</b> 1.50%
<b>B</b>	<b>SEPIPLUS™ 400</b> <b>SEPIPLUS™ S</b>	<b>0.75%</b> <b>0.75%</b>
<b>C</b>	<b>EMOSMART™ C28</b> <b>EMOGREEN™ L19</b> <b>LANOL 14M</b> <b>MONTANOV™ 202</b> <b>MONTANOV™ 68 MB</b> Cera Alba Stearate Glycerol	<b>5.00%</b> <b>3.00%</b> <b>2.00%</b> <b>2.00%</b> <b>2.00%</b> 1.00% 3.00%
<b>D</b>	<b>FLUIDIPURE™ 8G</b> <b>PHLOROGINE™ BG PF</b> <b>NATIVE ESSENCE™</b> Phenoxyethanol - Ethylhexylglycerin Phenylpropanol - Propanediol - Caprylyl Glycol - Tocopherol Parfum/Fragrance	<b>5.00%</b> <b>1.00%</b> <b>1.00%</b> 1.00% 0.40% 0.40%

With WESOURCE

**Glossy Black Thick Emulsion / Packaging: Tube****pH:** 6.4 / **VISCOSITIES:** **1M** at RT: 63,500 mPa.s Brookfield LV4-6.**Recovery at RT (after 1M at 45°C):** 48,500 mPa.s Brookfield LV4-6.**STABILITY:** 1M stable at RT & 45°C.**FORMULATION ADVICES: Pilot - 2 kg**

Heat ingredients of phase C under agitation with a hot water bath at 90°C. At the same time prepare aqueous mash by mixing ingredients of phase A' under agitation at 4000 RPM during 20 minutes. Add hot water of phase A into the phase A'. Add phase B into melted phase C. Emulsify adding phase C into phase A+A' at 4000 RPM during 4 minutes. Cool down at RT and under agitation at 500 RPM. Add phase D when the mix is <50°C under agitation at 300 RPM.

## A mask acting on equilibrium of your skin & well being!

This mask purifies the skin by limiting sebum excess thanks to two active ingredients: **PHLOROGINE™ BG PF & FLUIDIPURE™ 8G**.

**PHLOROGINE™ BG PF** (Aqua/Water - Butylene Glycol - Laminaria Saccharina Extract): Preservative free water soluble active from brown alga which **helps to regulate sebum**.

**FLUIDIPURE™ 8G** (Hexylene Glycol - Capryloyl Glycine - Xylitylglycoside): This is Pure protection from head to toe! **Controls sebum, decreases irritation, controls body odor & restore the skin's acidic mantle** (perfect match for **sensitive skin**). Participates to the microbial protection of cosmetic formulations.

**NATIVE ESSENCE™** detoxifies the skin.  
(Caprylic/Capric Triglyceride - Crithmum Maritimum Extract)

**PROTEOL™ APL EF** acts as a mineral pigment disperser in the aqueous mash preparation. (Sodium Cocoyl Apple Amino Acids)

**SEPIPLUS™ 400 & SEPIPLUS™ S** provide gliding and comfort during application with a cocooning sensorial feel. These liquid polymers make the aqueous mash dispersion easier.

**SEPIPLUS™ 400** (Polycacrylate-13 and Polyisobutene - Polysorbate 20): Allows a **good pick-up**.

**SEPIPLUS™ S** (Hydroxyethyl Acrylate / Sodium Acryloyldimethyl Taurate Copolymer - Polyisobutene - PEG-7 Trimethylolpropane Coconut Ether): Sensory profile: **feeling of long lasting comfort**. Good compatibility with pigments.

**MONTANOV™ 202 & MONTANOV™ 68 MB** provide a perfect smooth texture for a mask.

Promoters of liquid crystals, playing a role in maintaining skin moisturization over time:

**MONTANOV™ 202** (Arachidyl Alcohol - Behenyl Alcohol - Arachidyl Glucoside)  
**MONTANOV™ 68 MB** (Cetearyl Alcohol - Cetearyl Glucoside)

**EMOGREEN™ C28 & EMOGREEN™ L19** provide a light & fresh sensorial feel during application, followed by an extra comfortable sensation.

**EMOGREEN™ C28** (C21-28 Alkane) / **EMOGREEN™ L19** (C15-19 Alkane\*) (\* Renewable)

**LANOL 14 M** texturizes the mask & improve its consistency, without any soaping effect. (Myreth-3 Myristate)

**ADDITIONAL INGREDIENTS:** Phenoxyethanol - Ethylhexylglycerin; EUXYL PE9010 (SCHÜLKE & MAYR) / Phenylpropanol - Propanediol - Caprylyl Glycol - Tocopherol; SENSIVA P440 (SCHÜLKE & MAYR) / Argania Spinosa Kernel Oil; HUILE D'ARGAN (CRODA) / Colorant: SOLUTION BLEU AZUR1% +1% EUXYL PE9010 / Fragrance: PARFUM NEUTRAL (EXPRESSIONS PARFUMÉES).

### A formula related to MOOD PAINT concept

More informations available on [seppic.com](http://seppic.com)**SEPPIC**

All information contained herein is intended merely to demonstrate the utility of Seppic products, and should not be construed as granting license to practice any compositions or methods covered by a patent or a patent application. All information contained in this specific technical documentation is believed to be accurate and has been set up by Seppic according to its own described methods and processes. Seppic however does not assume any liability or risks involved in the use of its products for the preparation and the assessment of the hereinabove formulation since the condition of use are beyond its control. Seppic customer must insure that the duplication of the hereinabove formulation is not infringing any intellectual property rights and that it complies with any regulatory status.

A company  
**Air Liquide**  
HEALTH CARE