



MAKE UP

EU07500 | AIR LIGHT TINTED CREAM

So Soft & Powdery



W/O Emulsion

A	EMOGREEN™ L15	10.00 %
	Pigments	11.65 %
B	SEPIMAT™ SB	2.00 %
	SEPICIDE™ HB	1.00 %
	EASYNOV™	1.00 %
	Fragrance	0.30 %
C	Aqua/Water	Up to 100 %
	Glycerin	2.00 %
	SEPI NOV™ EMT 10	2.30 %

Dark Beige Tinted Cream / Packaging: Tube

VISCOSITIES: 1M at RT: 9,580 mPa.s Brookfield LV4-6.

STABILITY: 1M at RT, 40°C & 50°C /
2M in thermal cycles from -4°C to 40°C /
Stable 3M at RT.

FORMULATION ADVICES: Laboratory scale - 200 g

Mix phase A pigments in **EMOGREEN™ L15**. Homogenize during 5 minutes at 13 500 rpm with ultra turrax. Add phase B **SEPIMAT™ SB** and homogenize with ultra turrax during 2 minutes at 9 500 rpm. Add rest of phase B ingredients. In a separated beaker, prepare phase C: introduce water and glycerin. Sprinkle **SEPI NOV™ EMT 10** and mix until homogeneous phase obtention. Add phase (A+B) to phase C and emulsify during 8 minutes at 800 rpm.



COLD PROCESS

Light, covering & with a comfortable application, the foundation is your ally for a healthy glow effect!

EASYNOV™ offers an internal gelled aqueous phase, extra rich in water. (Octyldodecanol - Octyldodecyl Xyloside - PEG-30 Dipolyhydroxystearate)
EASYNOV™ is a liquid lipophilic emulsifier. It allows you to develop **Water-in-Oil emulsions** without wax and thus gives soft and silky texture without sticky or tacky effect. Thanks to its liquid form, the emulsions can be prepared by a **cold process**.

SEPI NOV™ EMT 10 brings a fresh skin feel.

(Hydroxyethyl Acrylate / Sodium Acryloyldimethyl Taurate Copolymer)

Powder polymer "2-in-1", thickening in a wide pH range (3-12), ready to use, with an excellent stabilizing properties at low level and in presence of a high percentage of oily phase. **Sensory profile: "satin" touch, fresh, glide-on.**

EMOGREEN™ L15 facilitates an homogeneous & light pigments

spreading (11%). (C15-19 Alkane*) (*Plant-based & Renewable)

Non polar & biodegradable, bio-sourced emollient. It's THE alternative to volatile silicone oils. High purity vegetable alkane. Beyond the **lightweight & non-greasy skin feel**, it gives a **powdery finish**.

SEPI MAT™ SB brings a soft & matte effect on the skin.

(Methyl Methacrylate Crosspolymer)

Consisting of **absorbent, soft microspheres**. Ideal for a **soft & matte skin appearance**.

SEPICIDE™ HB: preservative system.

(Phenoxyethanol - Methylparaben - Ethylparaben - Propylparaben - Butylparaben)

Liquid & easy-to-use preservative with a broad antimicrobial spectrum.

ADDITIONAL INGREDIENTS: Pigments: CI 77891 - Hydrogenated Lecithin (0,00 %); UNIPURE WHITE LC 981 HLC (SENSIENT) ; CI 77492 - Triethoxyacetyl silane (2,0 %); UNIPURE YELLOW LC 182 (SENSIENT) ; CI 77491 - Hydrogenated Lecithin (0,35 %); UNIPURE RED LC 981 HLC (SENSIENT) ; CI 77499 - Hydrogenated Lecithin (0,10%); UNIPURE BLACK LC 989 HLC (SENSIENT) / Fragrance: CORAZON (MLLE PARFUMETTE - ACCORD & PARF).

Labosphere development

Comfort foundation

Healthy glowing skin

More informations available on seppic.com**SEPPIC**

All information contained herein is intended merely to demonstrate the utility of Seppic products, and should not be construed as granting license to practice any compositions or methods covered by a patent or a patent application. All information contained in this specific technical documentation is believed to be accurate and has been set up by Seppic according to its own described methods and processes. Seppic however does not assume any liability or risks involved in the use of its products for the preparation and the assessment of the hereinabove formulation since the condition of use are beyond its control. Seppic customer must insure that the duplication of the hereinabove formulation is not infringing any intellectual property rights and that it complies with any regulatory status.

A company
Air Liquide
HEALTH CARE